

Cellular Phonebook Backup & Transfer Kit

FOR DUMMIES

Permanently backup your phonebook contacts with just one touch!


User Guide (Quick Start)

Package contains

- ✓ Cellular Phonebook Backup & Transfer For Dummies device
- ✓ Detachable phone tip(s)
- ✓ User Guide (Quick Start)
- ✓ Phone Specific Setup/Connection Guide

For additional support, please visit www.backup-pal.com/dummies

Illustrating the Cellular Phonebook Backup & Transfer For Dummies device



Getting Started

1. Insert 3 AAA batteries (not included) into the battery compartment at the back of the backup device.
2. Fully charge your phone prior to performing any operation.
3. Turn your phone off and then on again.
4. Set your phone options for Data connection. For some phone models, the USB Connection Settings must be set to proper Data mode to operate with your device. For further instructions, please refer to the included "Phone Specific Setup/Connection Guide" for your phone. You can also find more information online at www.backup-pal.com/dummies or refer to the user manual for your phone.
5. Exit all menu options and make sure your phone displays the main screen.
6. If you have a flip or slide phone, keep the phone in an open position during the operation.



Do not use the phone or any of its applications during use with the backup device.

Connecting Your Device

1. Plug in the Interface Adapter to the top of the device.
2. Attach the appropriate Detachable Phone Tip (if required).
3. Connect the backup device to the data-port on your phone. See the "Phone Specific Setup/Connection Guide" for compatibility information.



Data-port location may vary; please refer to the user manual for your specific phone.

Backing Up or Restoring Your Cellular Phonebook

1. Connect the backup device to your cellular phone. See the section "Connecting Your Device."

2. BACKUP/RESTORE instructions:

TO BACKUP:

Press and release the BACKUP button.



TO RESTORE:

Hold the RESTORE TO PHONE button for 5 seconds.



3. Observe the Status Light (LED) indication of the device progress as the operation is performed. See the Status Light Indication Guide to interpret the results.

STATUS LIGHT INDICATION GUIDE

ORANGE FLASHES	Detecting phone
ALTERNATING RED/GREEN	Set phone options for data connection (see Phone Specific Setup/Connection Guide)
ALTERNATING ORANGE/RED	Device contains data from another phone. To delete existing data, press and hold RESET for 5 seconds
GREEN FLASHES	Operation in progress
SOLID GREEN LIGHT	Operation completed successfully
SOLID ORANGE LIGHT	Operation completed (some data missing*)
RED FLASHES	
2 FLASHES	Phone not plugged in
3 FLASHES	Phone not supported
4 FLASHES	Data error; fully recharge your phone
SHORT FLASHES	Replace backup device batteries

Note: The Status Light Indication Guide is also available on the battery cover of the backup device.

*For more information, please visit our online FAQ section at www.backup-pal.com/dummies.

Checking Status of Last Operation

- ✓ **Checking backup status:** Quickly tap the BACKUP button twice and refer to the Status Light Indication Guide.
- ✓ **Checking restore status:** Quickly tap the RESTORE TO PHONE button twice and refer to the Status Light Indication Guide.

Important Security Feature!

To prevent overwriting/deleting existing data on your device, only data from one phone may be backed up at a time (based on phone's serial number). To backup data from another phone, you must first reset the backup device.

See "Clearing the Device Memory" for more information on deleting data on your backup device.

Clearing the Device Memory



1. Disconnect the device from your cellular phone.
2. Press and hold the RESET button for 5 seconds.

Note: During the RESET operation, the status LED/light flashes orange.

Experiencing Technical Difficulties?

Follow these steps:

1. Firmly grasp the Interface Adapter (the black area on top of the device), and gently pull it out.
2. Reinsert the Interface Adapter into the device.
3. Fully recharge your phone.
4. Restart and open (flip/slide) your phone before operation.
5. Wait one full minute before trying again.
6. Retry last operation.

Still experiencing technical difficulties?

Please visit our online support section at www.backup-pal.com/dummies.

Finding Your Cellular Phone Model Number

1. Turn off your phone and remove the battery.
2. Check the label beneath the phone battery for the model number.



Note: If you do not see your phone model listed on the compatibility charts, please visit our online compatibility section at www.backup-pal.com/dummies.

Got a new phone? Your backup device is upgradable.

When using the device to transfer contacts to a phone not compatible with your current backup device, please contact us to determine if a supporting upgrade kit (containing a new Interface Adapter or Detachable Phone Tip) is available for your new phone.

Making Everything Easier!™



Contact Us!
Web: www.backup-pal.com/dummies
E-mail: support@backup-pal.com
Phone: 1-818-847-0483

US Utility Patent #7349719
International Patents Pending
Made in China

© 2009 For Dummies, the Dummies Man logo, and related trade dress are registered trademarks of Wiley Publishing, Inc. Used by license.

Product Warranty

Subject to the provisions described below, this product is protected for ninety (90) days against defects in material and workmanship. Only consumers purchasing this product from an authorized AWS retailer may obtain coverage under this warranty. Any AWS products obtained from sources other than the authorized AWS retailers are not covered by this warranty.

AWS Duties Under This Warranty:

Should the product fail to perform within the warranted period as described in these instructions, it will be repaired or replaced with the same or functionally equivalent product by AWS, at its discretion, free of charge provided you:

- (1) Return the failed product to an AWS designated repair facility with shipping charges covered by the customer. (Please ship the failed product in the original or a properly padded, protective replacement container to an AWS designated repair facility.)
 - (2) Provide AWS with proof of the original purchase date.
- Repaired or replacement products will be returned to you with shipping charges covered by AWS. Replacement products may be refurbished or contain refurbished materials that have been tested to meet AWS specifications. AWS warrants any replaced or repaired product for a period of thirty (30) days from shipment, or through the end of the original warranty, whichever is longer. If AWS, by its sole determination, is unable to repair or replace the defective product, it will refund the depreciated purchase price of the product.

Important Note: By sending product for replacement, You agree to transfer ownership of the original product to AWS. AWS will not return your original product to You. Data recovery is not covered under this warranty and is not part of the repair or exchange process.

Limitation of Liability:

This warranty does not cover any problems caused by commercial use; accident; abuse; neglect; shock; electrostatic discharge; heat or humidity; improper installation, operation, maintenance or modification; any product with removed, damaged or tampered labels; malfunctions caused by other equipment; any misuse contrary to the instructions in the user guide; any damages from shipment, handling, or storage. This warranty does not cover data loss-backup of phonebook, contacts and/ or any other cellular phone content should be stored to an alternative medium in addition to this device. Also, consequential damages; incidental damages; and costs related to data recovery, removal and installation are not covered under this warranty. Except as specifically provided in this agreement or as required by law, the warranties and remedies stated in this document are exclusive and in lieu of all others, oral or written, expressed or implied. Any and all other warranties, including implied warranties of merchantability, fitness for a particular purpose and non-infringement of third party rights are expressly excluded. AWS shall not under any circumstances be liable to any person for any special, incidental, indirect or consequential damages, including without limitation, damages resulting from use or malfunction of the products, loss of profits or revenues or costs of replacement goods, even if AWS is informed in advance of the possibility of such damages. AWS' entire liability shall be limited to replacement, repair, or refund of the purchase price paid by you for the product, not to exceed any Manufacturer Set Retail Price (MSRP) by AWS for that product at AWS' option.

To Request Warranty Service:

Prior to returning any defective product, the end customer or the reseller from whom the end customer originally purchased the product must contact technical support to diagnose the product as defective and obtain a valid case number. Should Technical Support deem the product defective, a Return Materials Authorization (RMA) number and shipping instructions will be provided. AWS will not accept collect shipments - all defective products returned to AWS must have all shipping charges prepaid by the customer.

Legal Jurisdiction:

THIS WARRANTY AND AGREEMENT SHALL BE GOVERNED BY AND CONSTRUED IN ACCORDANCE WITH THE SUBSTANTIVE LAWS OF CALIFORNIA (USA). It gives You specific legal rights, and You may also have other rights that vary from state to state. This warranty does not affect any additional rights You may have under laws in your jurisdiction governing the sale of consumer goods. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the limitations or exclusions in this warranty statement may not apply to You. THE STATE AND FEDERAL COURTS LOCATED IN LOS ANGELES COUNTY, CALIFORNIA WILL HAVE EXCLUSIVE JURISDICTION OVER ANY DISPUTE ARISING OUT OF OR UNDER THIS AGREEMENT.



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.



This product has been tested and was declared to comply with the following standard(s) or specification(s) according to European EMC Directive 89/336/EEC
Emission: EN 55022: 1998 + A1:2000 + A2: 2003
Immunity: EN 55024: 1998 + A1: 2001 + A2: 2003, IEC 6100-4-2: 1995+ A11:1998 + A2: 2000, IEC 6100-4-3: 2002 + A1:2002

Cellular Phonebook Backup & Transfer Kit **FOR DUMMIES**

USB Setup Connection Guide

IMPORTANT! RESTORE OPERATION WILL REPLACE EXISTING DATA INSIDE PHONE

Step 1. Use chart below to select adapter tip for your phone.

USB Phone Tip Selection Chart				
BlackBerry	STORM Series	Curve Series	8800 Series	
	**9500M4 **9530M4	**8300USB **8310USB **8320USB **8330USB	**8800USB **8820USB **8830USB	
Motorola	BOLD Series	Pearl Series	Electron Series	
	**9000USB	**8100/8100cUSB **8110, **8120USB **8130USB **8220 FLIPM4	**700c/f/g/rUSB **8703eUSB Charm Series **7100USB **7100g/i/r/t/v/xUSB **6210USB	
HTC	KRAVE ZN4M3 KRZR **K1M3 K1m, **K3USB MOTO **Z9M4 PEBL U6USB	RIZR **Z3M3 Z6CM4 **Z6M, Z6TVUSB SLVR L2, **L7, L7cUSB L6, L6i, **L71, L72, **L9M3	C341a, C343M2 C343aM2 C350, C350gUSB C353, C353tM2 C650USB C975M2 E380USB E398M2 E790 (ROKR E1)M2 E815, E816M2 E1000, **E1070M2 L71, L72 (SLVR)M3 P280, T300P, T720i, T720c, T720g, T720i, T721, T722i, T725e, T730c, T731, T731i	
	RAZR Maxx Ve, V3, V3a, V3c, **V3i, **V3i (Dolce & Gabbana), V3m, **V3r, V3s, **V3t, **V3x, **V6 maxx, V3xxxUSB	ROKR **E1 (E790)M2 270cM2 A630, A840, A845M2 C290, C331gUSB C331tM4 C332, C333, C333c, C333gUSB	E790 (ROKR E1)M2 E1000, **E1070M2 L71, L72 (SLVR)M3 P280, T300P, T720i, T720c, T720g, T720i, T721, T722i, T725e, T730c, T731, T731i	T731cM2 V60, V60 Color, V60ci, V60g, V60gi, V60i, V60ic, V60ig, V60p, V60s, V60t, V60t Color, V60ti, V60x, V65P, V66, V66iM2 V70, V80, V120, V120c, V120e, V120t, V120xM2 V180, V188, V190, V195, V197, V220, V235USB V260, V262, V265, V266, V276, V300M2 V323iUSB
Nokia	Google Android GPhone	**T-Mobile G1USB		
	2000 Series 2865/2865iN2 3000 Series **3110 (Classic)USB 3155/3155iN2 **3500 (Classic)USB **3555/3555bM4 XpressMusic Series **5200/5200bUSB	**5300/5300bUSB **5310, **5610M4 6000 Series **6085/6086N2 **6111N2 **6125/6126N2 **6131N2 **6133/6133bN2 **6136N2 **6151N2 6155iN2	6165iN2 6170/6170bN2 6230/6230bN2 **6230iN2 **6233N2 **6234N2 6235iN2 6236iN2 6255/6255iN2 6256iN2 **6263N2	6265iN2 6651N2 7000 Series 7270/7270bN2 **7370N2 **7373N2 **7390N2 **7500 PRISMUSB 7600USB 6655/6555bUSB
Samsung	AX245L3 AX275L4 **AX300M4 AX355L3 **AX380 WAVEL4 AX390L3 AX490/AX490AL3 **AX565 MUZIQL4 **AX830 GLIMMERM4 AX4750L3 AX5000L3 AX8600L4	**SCH-U420S4 **SCH-U470 JUNES5 **SCH-U520S3 SCH-A610S3 SCH-A630S3 **SCH-A645S3 SCH-A650S3 SCH-A670S3 SCH-A790S3 SCH-A795S3 SCH-A850 (Verizon only)S3 **SCH-A870S3 **SCH-A930S3 SCH-A970S3 **SCH-A990S3 SCH-N330S3 SCH-R210S5 **SCH-R400 LIMES5 SCH-R410S5 SCH-R430 MY SHOTS5 **SCH-R500 HUES3 **SCH-R510 WAFERS4 **SCH-R610S5 **SCH-U300 (Verizon only)S3 SCH-U410S3	SGH-E870S4 SGH-E878S4 SGH-E900S4 SGH-M610S5 SGH-P300S4 SGH-T219S4 **SGH-T229S5 SGH-T309S3 SGH-T329 STRIPES5 **SGH-T339S5 **SGH-T409S5 **SGH-A436S4 **SGH-A437S4 SGH-D307S3 SGH-D347S3 SGH-D357S3 SGH-D407S3 SGH-D520S4 SGH-D806S4 SGH-D807S4 **SGH-D830S4 SGH-D840S4 SGH-D900iS4 SGH-D908S4 SGH-E840S4	SGH-X506S3 SGH-X507S3 SGH-X820S4 SGH-X830S4 SPH Series SPH-A420S3 **SPH-A560S3 **SPH-A580S3 **SPH-A600S3 **SPH-A620S3 **SPH-A660S3 SPH-A640S3 **SPH-A680S3 **SPH-A700S3 SPH-A800S3 SPH-A820S3 SPH-A840S3 SPH-A880S3 SPH-A900S3 SPH-A920S3 SPH-A940S3 SPH-A960S3 SPH-A320M4 SPH-M500S3 SPH-M510S5
	LG Series (CANADA) LG150L3 LG160L4 LG245L3 LG260 RUMORL4 LG285, LG380L4 LG490L3 LG550 FUSICL3 LG570 MUZIQL4 LG830 VANTAGEM4 LG8100L3 LG8500 CHOCOLATEL4 LG8550 CHOCOLATE SPINL4 LG8600 CHOCOLATE FLIPL4 LG8700 SHINEL4 LG8800 VENUSL4 LG9100 KEYBOM4	VX3400/VX3450L3 VX4650L4 VX4700L3 VX5200L3 VX5300L3 VX5400L4 VX5500M4 VX6000L3 VX6100L3 VX7000L3 VX8000L3 VX8100L3 VX8300L3 VX8350L4 VX8500 CHOCOLATEL4 **VX8550 CHOCOLATE IIL4 **VX8550A CHOCOLATE IIL4	**VX8560 CHOCOLATE IIIM4 VX8600L4 **VX8610 DECOYM4 VX8700L3 **VX8800 VENUSL4 **VX9100 enV2M4 VX9400L4 **VX9700 DAREM4 VX9800 The VL3 **VX10000 VOYAGERL3	
Sony Ericsson	K510E2 K550E2 K790E2 K790E2	S500E2 T650E2 TM506E2	W300E2 W350E2 W380E2 W550E2 W580E2 W600E2 W610E2	
			W660E2 W710E2 W800E2 W810E2 W880E2 W890E2 W900E2	

USB Phone Tips	
 <p>*USB Adapter Tip Not Needed</p>	
M2	M3
M4	S3
S4	S5
L3	L4
N2	E2

Note: Included phone tips may vary based on your kit (check compatibility chart on packaging)

IMPORTANT! ALWAYS FULLY CHARGE AND RESTART YOUR PHONE BEFORE USING DEVICE!

support@backup-pal.com
1-818-847-0483
www.backup-pal.com/dummies

** Important! See reverse side for additional steps.

Check other side for important instructions (Step 2.) >>

Step 2. Phones below require additional USB configuration.

Important! If your phone is listed below, follow the setup instructions provided before using your device.

Phone Models	Phone USB Configuration Instructions
BlackBerry All BlackBerry Phones Password Protected BlackBerry Phones Only	IMPORTANT: READ BEFORE RESTORING! To ensure BlackBerry device saves all phonebook entries during RESTORE TO PHONE operation: <ul style="list-style-type: none"> • Check to make sure at least one name/number is saved in the BlackBerry phonebook (not the SIM card, if any). • Check to see if your phone has a "Wireless Synchronization" option. If so, it must be turned off. Go to: Address Book ⇒ Menu (Press "BlackBerry" button) ⇒ Options ⇒ Wireless Synchronization ⇒ Select: NO Disable Password Protection (Content Protection) before operation Option 1: Go to: Options ⇒ Security Options ⇒ General Settings ⇒ Password (or Content Protection) ⇒ Select: Disabled Option 2: If password cannot be disabled, then your BlackBerry Device must be controlled by the BlackBerry Enterprise Server: <ul style="list-style-type: none"> • As an alternative, the following models will prompt you to enter your password during a Backup-Pal Backup/Restore operation: <ul style="list-style-type: none"> o 8700c, 8700r, 8703c, 8800, 8820, 8830, 8100, 8110, 8120, 8300, 8310, 8320, 8330, 8220, 9000, 9500, 9530 o Backup-Pal will blink alternating Red/Green for 1 minute, during which the correct password must be entered on the phone prompt. Important! Set security timeout for 9000 BOLD: Go to: Options ⇒ Security Options ⇒ Password ⇒ Security Timeout ⇒ Set: 1 hour • If password cannot be disabled, for the following older models you will need to contact your enterprise server administrator to enable that option before Backup-Pal may be used with your phones: <ul style="list-style-type: none"> o 6210,6230,6280,6290, 6510, 7100g, 7100i,7100t,7100v, 7105t, 7210, 7250, 7280, 7290, 7510
Motorola KRZR K1, L7, L71, L72, L9, RAZR V3i, V3r, V3t, RAZR2 V9, ROKR E1, E1070, V360, V361, V365, Z9 RIZR Z3 KRZR K3 RAZR V3x, V6 Zōm KRZR K1m Alltel RAZR2 V9m E816, W490, W510 RAZR V3xx Cingular	Set phone connection options to Data/Fax Connection mode: Go to: Menu ⇒ Settings ⇒ Connection ⇒ USB Settings ⇒ Default Connection: Data/Fax Connection Set phone connection options to Data Connection mode: Go to: Menu ⇒ Settings ⇒ USB settings ⇒ Default Connection: Data Connection Set phone connection options to Data Connection mode: Go to: Menu ⇒ Connection ⇒ USB settings ⇒ Default Connection: Data Connection Set phone connection options to Modem/Computer mode: Option 1: Remove the Memory Card Option 2: Go to: Menu ⇒ Settings ⇒ Connection ⇒ USB settings ⇒ Default Connection: Data Connection Set phone connection options to Computer or Data mode: Go to: Menu ⇒ Settings ⇒ Connection ⇒ USB settings ⇒ Default Connection: Computer or Data
HTC T-MOBILE ANDROID G1	Important! Make sure that the MEMORY CARD is installed. Before any operation, set phone connection options: <ol style="list-style-type: none"> 1. Go to: Settings ⇒ Applications ⇒ Select: Unknown Sources : ON 2. Go to: Settings ⇒ Applications ⇒ Development ⇒ Select: USB Debugging: ON, Stay Awake: ON
Nokia 3110c, 3500c, 5300/5300b, 6085, 6086, 6111, 6125, 6126, 6131, 6133/6133b, 6136, 6151, 61651, 6233, 6267, 6275i, 6280, 6288, 6300, 6301, 7370, 7373, 7390, 5200, 7500(PRISM) 5310, 5610, 6500 (Slide), 6500(Classic) 6263, 6555/6555b, 3555b 6230i	During BACKUP or RESTORE TO PHONE operation your phone will prompt "USB Data cable connected. Select Mode": <ol style="list-style-type: none"> 1. Press "OK" on the phone to continue. 2. Then your phone will prompt you to select a mode: Choose "Nokia Mode" or "Default Mode," then press "OK" on the phone to continue Set phone USB Mode to "PC Suite": Option 1: During BACKUP or RESTORE TO PHONE operation when prompted "Select USB Mode," select "PC Suite," then press "OK" Option 2: Go to: Menu ⇒ Settings ⇒ Connectivity ⇒ USB Data Cable ⇒ Set Default USB Mode to "PC Suite" During BACKUP or RESTORE TO PHONE operation phone will prompt for selection of "USB Mode" or "Music Sync": While Backup-Pal is flashing Red/Green: Go to: Menu ⇒ Settings ⇒ Connectivity ⇒ USB Data Cable ⇒ Select: "Nokia Mode" Disable "Data Storage Device" USB Mode on the phone: Option 1: Remove the Memory Card (if any) Option 2: During BACKUP or RESTORE TO PHONE operation when prompted "Use phone as data storage device?," select "Reject"
Samsung SPH-A700, SPH-A560, SPH-A420, SPH-A820 SCH-A645, SPH-A700, SCH-U340 SPH-A580, SPH-A600, SPH-A620 SPH-A660, SPH-A680, SPH-A840 SPH-A580 SGH-T229, SGH-T339, SGH-T409, SGH-T429, SGH-A436, SGH-A437, SGH-T229, SGH-T739, SGH-D830 SGH-D900i SGH-E840 SGH-T539 BEAT SGH-U100 SGH-U600 SGH-X830 SGH-M610 SGH-T729 BLAST SPH-A680 SCH-U470 JUKE SGH-T439, SGH-D908 SPH-M800 INSTINCT SCH-A870, SCH-A930, SCH-A990, SCH-R400 SCH-R510, SCH-R610, SCH-U420, SCH-U520 SCH-U706, SCH-R500, SCH-U900	Phone limitation: Phonebook Note Fields WILL NOT be backed up or restored. Phone limitation: Phonebook Nickname Fields WILL NOT be backed up or restored. Phone limitation: Phonebook Birthday Fields WILL NOT be backed up or restored. Phone limitation: Phone returns Blank E-mail if Phonebook E-mail contains over 71 characters. Important! Phone must be FULLY CHARGED before using with backup device. Otherwise, the backup will not work due to the phone's limitation. Before any operation: Set phone connection options to Modem mode: Go to: Menu ⇒ Setting ⇒ Phone Settings ⇒ USB Settings ⇒ Select: Modem Phone limitation: Only first 20 characters of Phonebook Note Fields can be backed up. 1. Important! Phone must be FULLY CHARGED before using with Backup-Pal. Otherwise, the backup will not work due to the phone's limitation. 2. Select "USB Mode" settings: Option 1: During BACKUP/RESTORE TO PHONE operation: • Phone will prompt "USB Mode" selection: Select "PC Studio" option Option 2: Before any operation • Go to: Menu ⇒ Setting ⇒ USB Settings ⇒ Select: "PC Studio" 1. Important! Phone must be FULLY CHARGED before using with Backup-Pal. Otherwise, the backup will not work due to the phone's limitation. 2. Before any operation, select "PC Studio" mode: • Go to: Menu ⇒ Setting ⇒ Phone Settings ⇒ USB Mode ⇒ Select: "PC Studio" Extremely Important Information! Phonebook E-mails longer than 32 characters cause this phone to shut down during BACKUP operation. Please ensure E-mail addresses for all contacts have less than 32 characters before backing up any SPH-A680 phones! Other phone limitation: Phone returns Blank Address Field if Phonebook Address contains over 71 characters. Important! Before any operation, follow these steps on the phone to set MTP Setting: 1. Go to: Menu ⇒ Settings & Tools ⇒ "OK" 2. Enter #000000 on phone keypad ⇒ "OK" 3. MTP Settings ⇒ "OK" ⇒ MSM ⇒ "OK" ⇒ Press "END" 1. Important! Phone must be FULLY CHARGED before using with Backup-Pal. Otherwise, the backup will not work due to the phone's limitation. 2. Before any operation, select "Modem" mode: • Go to: Menu ⇒ Settings ⇒ Phone Settings ⇒ USB Settings ⇒ Select: Modem Important! Before any operation, remove MEMORY CARD from the phone's slot. Before any operation, select USB mode : • Go to: Menu ⇒ Settings ⇒ Phone Settings ⇒ PC Connection ⇒ Select: USB Before any operation, select "USB Modem" mode: • Go to: Menu ⇒ Settings ⇒ Phone Settings ⇒ PC Connection ⇒ Select: USB Modem Before any operation, select "USB Modem" mode: • Go to: Menu ⇒ Settings & Tools ⇒ USB Auto Detection ⇒ Select: USB Modem
LG AX300, AX380 GLIMMER AX565, AX380 VX8550(CHOCOLATE II) VX8550A(CHOCOLATE II) VX8560(CHOCOLATE III) VX8610 DECOY, VX8800 VENUS VX9100 enV2, VX9700 DARE VX10000 VOYAGER LX570 MUZIQ	1. Important! Phone must be FULLY CHARGED before using with Backup-Pal. Otherwise, the backup will not work due to the phone's limitation. 2. Before any operation, select "USB Modem" mode: • Go to: Menu ⇒ Settings ⇒ PC Connection (USB Connection): Modem 1. Important! Phone must be FULLY CHARGED before using with backup device. Otherwise, the backup will not work due to the phone's limitation. 2. Set "Data" Sync option on the phone: Option 1: During BACKUP or RESTORE TO PHONE operation • Phone will prompt "Select Sync option for USB connection" selection; select "DATA" option Option 2: Before any operation • Go to: Menu ⇒ Settings & Tools ⇒ USB Settings ⇒ USB Auto Sync (or USB Auto Detection): Sync Data During BACKUP or RESTORE TO PHONE operation phone will prompt, "USB Connection: Press OK to enter": • No action required; Backup-Pal will connect automatically.
SE Sony Ericsson Z750	Before any operation, set the "USB Default Mode" to "Phone Mode": • Go to: Menu ⇒ Setting ⇒ Connectivity ⇒ USB ⇒ USB Default Mode: Phone Mode